



master®
FIREPLACES

Brilliant heat.
Beautiful to watch.



The ultimate choice in wood fires



Jetmaster 850 Golf Links Dethi



Jetmaster 850 Ludhiana

"I came to India with the dream of turning on Indian households to the beauty and sacredness of fire for their homes. After 5 years with Australia's leading open fireplace brand, Jetmaster, we have transformed and continue to transform countless Indian homes with the joy, sacredness and beauty of fire."

Daniel Belnick Director, Master Fireplaces



Asia Spa Dharamshala

BUILDING A NEW OPEN WOOD FIREPLACE IN AN EXISTING ROOM/HOME HAS NEVER BEEN EASIER.

Just follow these simple steps:



Step 1

Place the firebox and gather on a solid non-combustible base and vent chimney pipe and continue all the way through to the roof.



OR – Step 1a

Install firebox and gather on a base and penetrate the wall with a 45 degree elbow and terminate chimney pipe above the roof. Master Fireplaces offer a range of flashing options to assure no water ingress in roof or wall penetrations.



Step 2

Complete minimal specified brick-work or AAC block work around the firebox and gather.




Step 3

Complete chimney breast using brick work or gypsum board.



Step 4

Installation complete.



Jetmaster

Australia's premier open fireplace
now in India



Jetmaster, Australia's leading fireplace brand, is designed not to smoke into the room. Jetmaster offers five times more heat than a traditional fireplace as well as unlimited design versatility. No full brick chimney is required, therefore designs are far more versatile compared to a traditional brick fireplace.



Bring the bonfire home



Fireplaces transform a room and create an ambience that no other feature in your home can emulate. Fires are simply magical.

All homeowners and designers know that when there is a fireplace in a room, the ambience of the room is dramatically changed. Why?

The warmth and golden light radiating from the crackling flames fills the room. Fireplaces evoke feelings of homeliness, family and friends, stories told and shared.

Remembering the bonfire

Remember that feeling of peace and contentment that descended on you as you watched the glowing embers and leaping flames of a bonfire under the stars?

A fireplace is your bonfire at home.

WHY JETMASTER IS THE WORLD'S FINEST OPEN FIREPLACE

Jetmaster makes installing an open wood fireplace a breeze.

A Jetmaster can be installed with minimum brickwork and finished with timber framing and plasterboard, saving you thousands on installation costs.

Jetmaster is uniquely designed not to smoke into the room.

A Jetmaster is designed not to smoke back into the room, so you can enjoy round-the-room comfort.

Minimal cleaning and easy to light.

All the ash burns down to a fine powder in the deep logpan, ensuring cleaning only once or twice a season. The remaining coals and ash also makes it easy to light your next fire.

Jetmaster's unique two-way radiant and convection heating system.

In a conventional open fireplace, all the heat gets lost up the chimney. However, with a Jetmaster, the metal insert reflects heat. Added to this is the unique convection chamber which gives you round-the-room comfort.

Screened for safety.

Jetmaster's hook-on flush fitting protective screen offers you total peace of mind for overnight burning.

A Jetmaster fireplace transforms a home.

Fire (one of the 5 elements of Ayurveda) is transforming, purifying, bringing joy, warmth and comfort to a home. There is nothing quite like an open fireplace and there is nothing quite like a Jetmaster – the world's finest open fire.

Beauty you can see through – double-sided options



Universal 700
Double-Sided
Wood Fire



Jetmaster 700 Double-Sided Wood Fire



Jetmaster 1050 Double-Sided Wood Fire



Convert your existing fireplace to the efficiency of a Jetmaster wood fire

Converting your existing fireplace to a Jetmaster wood or gas fireplace dramatically increases efficiency, eliminates smoking problems and transforms your smoky hole in the wall to a beautiful centrepiece.

As no flue is required (a Jetmaster will operate beautifully off the existing chimney), the installation is easy and cost effective. You can do it yourself or use our qualified installers. Jetmaster also supplies fascias, extensions, surrounds, mantels, and trims. Everything you need to renew your old fireplace and make it work much better than ever before.



Step 1: Measure the height, depth and width of your fireplace recess.




Step 2: Choose the appropriate firebox from a range of sizes.



Step 3: Installation complete with Universal 600, Plain arch fascia standard coals and white MDF Richmond mantelpiece.

Specifications

(Dimensions in millimetres)



	Jetmaster Universal						Heating Capacity (Sq.m)	
	A	A1	B	C	D	E	Wood	Gas***
440	470	510	330	610	200	200	25	25
500	570	600	350	650	200	200	25	25
600	670	700	350	650	200	200	40	40
600 LOW	670	700	350	600	200	200	40	40
700SH	770	800	350	650	200	200	50	50
700SH LOW	770	800	350	600	200	200	50	50
700D	770	800	400	700	225	200	60*	50
850	920	950	450	750	250	220	80	60
850 LOW	920	950	450	700	250	220	80	60
1050	1120	1150	500	800	300	240	100	-
1050 LOW LOW	1120	1150	500	700	300	240	100	50
1200	1250	1300	605	1020	250**	400	150	-
1500	1550	1600	605	1020	300**	400	150	-

*Tested to 15Kw at maximum burning.

**Requires 2 flue outlets (single flue option also available).


***Depending on type of burner.

GAS APPROVED

Jetmaster gas burners are AGA approved as type 1 appliances.

WOOD APPROVED


Jetmaster Fires have qualified for the National Certificate of Exemption for Solid Fuel Heaters. This certificate is issued under Section 14 of the relevant legislation in that the maximum Carbon Dioxide output from the combustion chamber is less than 5% of the volume of the appliance.



	Jetmaster Double-Sided						Heating Capacity (Sq.m)	
	A	B	C	D	E	F	Wood	Gas**
700	850	800	610	700	220	345*	60	40
1050	1205	1150	600	770	233	455	80	-

*NB: A 300mm flue can be used with gas.

**Depending on type of burner.



	Jetmaster Freestanding				Heating Capacity (Sq.m)	
	A	B	C	D	Wood	Gas*
600	1000	390	845	200	50	50
700SH	1050	390	845	200	60	50
700D	1100	440	945	225	80	60
850	1200	490	995	250	100	70

*Depending on type of burner.

THE JETMASTER GUARANTEE

Provided the Jetmaster Fireplace is installed according to Jetmaster instructions and a Jetmaster receptacle is used for fuel burning, the unit* is unconditionally guaranteed for a period of 15 (fifteen) years (excluding rust) from the date of installation of the fireplace. *Not including the log pan, glass doors or gas burner.

"One of the best ways to address climate change is to use more wood not less. Wood is simply the most abundant biodegradable and reusable material on the planet."

- Patrick Moore, Co-founder of Greenpeace, *Washington Times*, January 2006.



Heat your home and reduce greenhouse gases

1. Burning wood in a Jetmaster open fire produces efficient home heating energy.
2. CO₂ is created by bush fires and decomposition. No energy is wasted when wood is burnt in a Jetmaster open fire.
3. CO₂ is absorbed by trees when growing.
4. O₂ is released into the atmosphere resulting in reduced greenhouse gas emissions.
5. Jetmaster supports the Firewood Association of Australia. Firewood merchants accredited by the F.A.A are able to supply sustainable dry fuel for use in efficient approved fireplaces. Use of sustainable dry fuel will not cause adverse air quality.
6. Burning fossil fuels such as coal fired electricity, oil and gas adds to greenhouse.

Visit your Master Fireplaces showrooms:

Delhi 132 Mehrauli Gurgaon Rd, Ghitorni (opposite Metro Pillar 132)

Nilgiris Kettikambai Main Rd, Thandanadu Kotagiri, Tamil Nadu

Phone 1800 3012 1007

Email: sales@masterfireplaces-in



Disclaimer: All products are subject to availability and may be changed without notice.

www.jetmaster.com.au

www.masterfireplaces.in